


OWNER'S MANUAL

Model: FSTS-15-BLU (5302838-BLU)

(15 Gallon Lawn & Garden Trailer Sprayer, Boom Ready)



General Information

Thank you for purchasing this product. The purpose of this manual is to assist you in operating and maintaining your trailer sprayer.

BEFORE RETURNING THIS PRODUCT FOR ANY REASON, PLEASE CALL

BAKERSFIELD, CA 877-724-2236	COLUMBUS, NE 800-274-1025	DOTHAN, AL 800-227-4098
FARGO, ND 701-280-2862	HOPKINSVILLE, KY 800-637-7172	MANKATO, MN 507-388-6295
NEWTON, KS 800-394-7662	PASCO, WA 800-634-2026	PHOENIX, AZ 877-974-7166

SOUTH CHARLESTON, OH
937-620-1710

If you should have a question or experience a problem with your Ag Spray Product: Visit our website @ www.agspray.com or call the Toll free number above. Our technical support representatives will be happy to help you.

In most cases a customer service rep. can resolve the problem over the phone.

To obtain prompt, efficient service, always remember to give the following information....

- Correct Part Description and/or part number
- Model number and Serial Number

Retain a copy of your receipt for your unit, as it will be required to validate any warranty service.

Warranted against manufacturer or workmanship defects from date of purchase with copy of receipt:

Homeowner Usage: One Year

Commercial Usage: 90 Days.



WARNING: Cancer and Reproductive Harm.
www.P65Warnings.ca.gov




WARNING: To reduce the risk of injury, the user must read and understand the operator's manual before using this product.



NOTE: Maximum Speed - 5 MPH
Refer to vehicle's manual for towing instructions.

IMPORTANT REMINDER



Occasionally check strainer screen to ensure it is clean and clear of any debris. Strainer is located on the end of the intake hose, inside of the tank. Use protective gear when removing hose from tank and cleaning the strainer.




www.agspray.com

[5196186

(12/25)]

Contents

Technical Specifications.....	2	Pump Information	7
Sprayer Contents	3	Troubleshooting	7
Sprayer Assembly Instructions	4	Sprayer Exploded View	8 - 9
Operation	5	Sprayer Parts List.....	9
Maintenance and Tank Care.....	6	Sprayer Dimensions	10
Winter Storage	6	Warranty	12



Model: FSTS-15-BLU (5302838-BLU)

(15 Gallon Lawn & Garden Trailer Sprayer)

Technical Specifications

- 15 Gal. Corrosion-Resistant Polyethylene Tank
- Squeeze Lever Handgun
- 15 Ft. Handgun Hose
- 12 Volt Diaphragm Pump, 2.2 GPM, 60 PSI
- 410/350 x 6" Wheel
- Boom-Ready

Caution: Always check the vehicle load rating before using the sprayer.

The loaded weight of this sprayer and boom assembly is approx.: 230 lbs. when the tank is full.

~~~~~IMPORTANT~~~~~

Remove tank lid and be sure the tank is clean and free of any foreign material. Rinse tank out of any tank residue before filling with water to test.

~~~~~IMPORTANT~~~~~

It is VERY important to test this sprayer with plain water before actual spraying is attempted. This will enable you to check the sprayer for leaks without the possibility of losing any expensive chemicals.

~~~~~WARNING~~~~~



Read and Understand the Owner's Manual completely before using this sprayer. Assemble, test and use in accordance to manual instructions.

Read and Follow chemical label instructions and wear protective gear when filling, using, cleaning and servicing the sprayer.

Exercise Caution in vehicle handling when towing/hauling a filled sprayer to avoid loss of control or overturning.

Keep Sprayer and Spray materials away from other people, children and pets.

Do Not Turn on Power to the sprayer, until ready to spray in order to avoid unintentional spray release.

Slow down before turning and do not turn sharply. Use wide turns to ensure sprayer follows path of towing vehicle.

Do Not Use on steep slopes. A full sprayer could cause loss of control or overturn sprayer and towing vehicle.

Always operate up and down a slope, never across the face of a slope.

Keep all movement on slopes slow and gradual. Do not make sudden changes in speed, directions or turning. Do not start or stop suddenly when going uphill or downhill.


Stop on level ground, set the parking brake and shut off engine before leaving the operator's position for any reason.

Keep all parts in good condition and properly installed. Fix damaged or worn parts immediately.

Caution should be taken when towing and/or using any sprayer. This sprayer combined with the weight distribution, turning radius and speed of towing vehicle can result in damage to towing vehicle and/or attachment or severe injury or death, if not used properly.

Improper use of this sprayer or handling of chemicals could result in serious injury or illness, or could cause damage to the environment.


Sprayer Contents:




Owner's
Manual



Tank/Plumbing
Pre-Assembly




Lid
w/Lanyard




RH Boom
Mount

LH Boom
Mount




Tongue
Weldment




Boom Feeder Hose, 1/2" - 1 Brd. x 43"

4.10/3.50-6
Wheels




Contents of Parts Bag #5277616



Ref. #	Part #	Description	Qty
1	5277040	Lead Wire Assembly (14 ga, w/Switch), 120"	1
1.1	5157238	15 Amp Regular Blade Fuse	1
2	5117323	5/16-18 x 0.75 Flng Hex Bolt	4
3	5006307	5/16-18 Serrated Flng Hex Nut	4
4	5101065	Hair Pin, #211 x 2.50	2
5	5167004	Pressure Gauge, 0-200# (Dry)	1
6	5051114	Hose Clamp (1/2")	2
7	5053096	Spray Wand Clip, for Blow-Molded Tanks	2
8	5117334	#10-24 x 0.50 PH Round Head Screw	2
9	5117307	3/8-16 x 1.00 Flng Hex Bolt	4
10	5006259	3/8-16 Serrated Flng Hex Nut	4

Assembly Procedure




- This sprayer is mostly assembled at the factory.
- Follow the instructions below to fully assemble the sprayer.
- **Make sure all hose clamps are tight** before testing or spraying for the first time.
- One requirement will be to hook up the battery leads to a fully charged 12 Volt battery.
- The drain plug assembly should already be attached to the tank

Right Hand (RH) and Left Hand (LH) sides of the sprayer are determined as if you are standing behind the sprayer, looking at it (facing forward)

Step 1:

Bolt the tongue to the frame with the hardware provided.



Step 2:

Affix the tires over the axle (valve stem out) and secure in place with the provided cotter pins.



Step 3:

Thread the pressure gauge into the manifold on the pressure side of the pump. Hand tight should be sufficient.

**** DO NOT OVER-TIGHTEN ****

Step 4:

Locate the (2) clips and (2) screws from the parts bag.




A Phillips screwdriver is required for this step

Place a screw through the hole in the clip and bring it up to the tank, where the embossments for the clips are (located on the rear side of the tank).

Secure the clip/screw to the tank. Tighten so that the clip is secure. Do this for each clip.

**** DO NOT OVER-TIGHTEN ****



The spray wand will snap into the clips

once installed. Do not use excessive

force when placing the spray wand into the clips, as this could cause the clips to break.

Step 5:

Attach the boom brackets to the frame.

If applicable, attach your boom to the boom brackets and route the boom feeder hose back to your boom. Secure in place with a hose clamp.

NOTE:

Make sure this boom feeder hose once connected to a boom, does not end up on the 'outside' of the spray wand hose, otherwise unwrapping the spray wand hose from around the tank may be difficult.

****The Sprayer is now ready to TEST w/plain water before actual use****

IMPORTANT: Remove tank lid and be sure the tank is clean and free of any foreign material. Rinse tank out of any tank residue before filling with water to test.

Testing the Sprayer

NOTE:

It is VERY important to test this sprayer with plain water before actual spraying is attempted. This will enable you to check the sprayer for leaks without the possibility of losing any expensive chemicals.

Fill the tank about 1/2 full with plain water and drive to the starting place for spraying.

When you are ready to spray, turn the boom valve to the “on” position (Detail A). This will start solution spraying from the tips of the boom. The pressure will decrease slightly when the boom is spraying.

Adjust the pressure by turning the “ON/OFF” valve lever on the Press. Adj. (bypass) line valve (Detail B). Make sure your pattern is sufficient. You may down-pressure the system by ‘bypassing’ solution back into the tank. This is achieved by opening the Press. Adj. (bypass) valve. Regulating pressure is done in this manner.

Read the operating instructions and initially begin spraying by closing the ‘Pressure Adjust’ valve and opening the boom line valve (Detail A). This will enable the air in the line to be eliminated (purged) through all the tips, while building pressure. When everything tests all right (no leaks and good pressure), add the desired chemicals to the mixture and water combination and start your spraying operation. Adjust the pressure and spray as you did in the testing procedure.

Conditions of weather and terrain must be considered when setting the sprayer. Do not spray on windy days. Protective clothing must be worn in some cases.

Be sure to read the chemical label(s) before application!

Operation

The pumping system draws solution from the tank, through the strainer and to the pump. The pump forces the solution under pressure to the handgun or boom nozzles.

Fill the tank part way with water and then add the desired amount of chemical to be sprayed. Finish filling tank to proper level.

Only fill the tank with what you’re going to spray in a day, never leave chemicals sit in tank.

Connect the lead wire to a fully charged 12 volt battery. You may use either a stand-alone battery or the battery on your towing vehicle. Connect to the positive (red) terminal first, then connect to the negative (black) terminal. Then connect the end of the lead wire to the end of the pump. When disconnecting, disconnect the end of the pump wire from the lead wire, then disconnect the negative (black) connection and finally the positive (red) connection. The lead wire has an On/Off switch to activate the pump. “-” is on and “O” is off. Turn the pump on by depressing the “-” side of the rocker switch.

The pump is equipped with a pressure switch that is pre-set at the factory to shut the pump off when all discharges are closed.




The pump will turn back on when one of the following actions occurs:

- ◆ Handgun lever is squeezed to spray the handgun.
- ◆ Boom valve is opened to broadcast spray with the boom.
- ◆ Bypass valve is opened to re-circulate solution back into the tank.

When spraying with either the boom or the handgun, pressure may be reduced by slowly opening the bypass valve until desired pressure is achieved. Opening the valve decreases pressure, closing the valve increases pressure. When spraying with the boom, the proper method to set the pressure is to open the boom valve completely and if a lower pressure is desired, then slowly open the bypass valve until that pressure is obtained.

For the safest and most efficient chemical application, you will need to calibrate your sprayer using the tip and speed charts, follow instructions in your boom manual. Once you have determined the proper speed and pressure settings, you will need to consult your chemical label for the amount of chemical to be added to the tank. Read the entire label. Use only according to label directions.

Manifold Valves CLOSED



Maintenance During/After Spraying

Periodically check the strainer and clean the screen on your intake line.

If sprayer becomes clogged during use, discontinue use immediately. DO NOT attempt to service while chemicals are in the sprayer and power is connected.

Proper care and maintenance will prolong the life of your sprayer.

After use, drain the tank and store or dispose of chemical properly. Fill the sprayer half way with clean water. Start the pump and allow the water to pump through the entire plumbing system and nozzles. Drain and then refill half full, add the recommended amount of a good quality tank cleaner, such as FIMCO Tank Neutralizer and Cleaner. (If no tank cleaner is available, you may substitute dish soap for this step, about 1-2 oz. per gallon). But a neutralizer/cleaner should be used to thoroughly clean the system. Turn pump on and circulate through system for 15 minutes and then spray out through boom and handgun nozzles. Refill sprayer half way with clean water and repeat. Follow the chemical manufacturer's disposal instructions of all wash or rinsing water.

If boom (if applicable) or handgun nozzles need cleaning, remove them from the sprayer and soak in warm soapy water. Clean with a soft bristled brush or toothpick if necessary. Never use a metal object. Even the slightest damage can change the flow rate and spray distribution. Water rinse and dry the tips before storing.

WARNING: Some chemicals will damage the pump valves if allowed to soak untreated for a length of time! ALWAYS flush the pump as instructed after each use. DO NOT allow chemicals to sit in the pump for extended times of idleness. Follow the chemical manufacturer's instructions on disposal of all waste water from the sprayer.

Tank Care & Maintenance

Warning: Do not use the tank as a container for fuel oils, kerosene, gasoline or any other petroleum distillate product. All polyolefins are softened and permeated by such products. In an enclosed area the vaporization of these materials from the outside surface of the tank could create a dangerous condition.

The tank should not be used as a pressure vessel nor used with chemicals or solutions having a weight of more than 12 pounds per gallon.

Store the tank in a dry dark place when not in use. Storage out of sunlight will prolong the life of the tank.

Do not drop, strike or kick the tank, especially at low temperatures. Tanks become brittle and are subject to cracking at temperatures below 20° Fahrenheit.

Always flush the tank with water and a neutralizing agent at the end of each use, to prevent contamination of solutions.

Winter Storage

Prepare the sprayer for end-of-season storage by running RV antifreeze through the system. This will keep internal parts lubricated, protect against corrosion and keep the unit from freezing. *Note: RV antifreeze is non-toxic and biodegradable and generally safer for the environment than automotive antifreeze.*

Before storing your sprayer for winter or long term storage, thoroughly clean and drain it as much as possible. Then pour enough pink RV antifreeze into the tank so that when the pump is turned on you can pump the antifreeze throughout the entire plumbing system, including the bypass. Make sure to operate the handgun until you see pink fluid spraying from the nozzle. Leave any remaining antifreeze in the tank. Before your next usage, rinse the antifreeze from the sprayer with clean water.

It is nearly impossible to drain all of the water from the sprayer and any trapped water can freeze in cold weather and damage parts of the sprayer. Pumping the antifreeze through the system will displace the water and help prevent this damage.


Removing from storage: drain the antifreeze. Fill the tank with fresh water and run through the system. Dispose of antifreeze and flush water properly.




- Clean and rinse your pump after each use with Fimco Tank Neutralizer
- Winterize your pump or sprayer by rinsing, draining and running RV Antifreeze through it before storing for the winter.
- Use clean water for your spray mixture
- Store inside a building when not in use.



- Use to pump bleach.
- Use to pump petroleum products such as diesel fuel, gasoline or kerosene.
- Use to pump chemicals w/petroleum distillates or surfactants.
- Leave pump sit with spray mixture in it for extended periods.
- Use dirty or unfiltered water for spraying.



AgSpray Prime Pump
2.2 GPM, 60 PSI
#5283303
(Model: AGR3-22060-1131)




Ref. #	Part #	Description	Qty
1	5151249	Complete Pumphead Assembly	1
1.1	5157299	Pressure Switch Assembly	1
1.2	5053120	Pump Slide Clip	2
1.3	5283101	Valve Housing Assembly	1
1.4	5151250	Lower Housing Assembly	1
2	5029248	Pump Feet	4


Before Troubleshooting or Attempting to Service the Pump:

- ♦ **Review Troubleshooting Chart:** Do Not attempt to repair until steps below are followed.
- ♦ **Personal Protective Gear:** Wear protective gear when servicing pump.
- ♦ **Disconnect Power:** Disconnect the power to the pump and relieve the pressure from the system.
- ♦ **Empty and Flush** the pump system with water, never attempt to service the pump until it has been emptied and flushed.
- ♦ **Perform Repairs:** Follow directions provided in the troubleshooting section to repair the pump.
- ♦ **Test:** Always test the pump for leaks with plain water after any repairs before using.


Troubleshooting			
Pump will not run:	Check for loose wiring		
	Make sure the ON/OFF switch is on		
	Check the fuse		
	Check for defective pressure switch		
	Check to see if connected to good 12 Volt Power Source		
	Check for Low Voltage		
Pump Does Not Prime (No Discharge w/Motor Running)	Check for clogged strainer/filter		
	Check for kinked inlet/outlet hoses		
	Check for empty product supply		
	Check for debris in check valve assembly		
	Check for defective check valve		
	Check for cracks in the pump housing		
Low Pressure/ Low Flow:	Check for air leaks in supply line		
	Check for a clogged strainer		
	Check for proper voltage		
	Try another 12-Volt battery		
	Check for leaks in the discharge line		
	Check for restrictions in the discharge line		
Pump surges:	Check for debris in intake		
	Check for debris in nozzle orifice		
	Low flow may cause pump to surge		
	Spray Wand is adjusted to small or fine of a spray pattern		
	Check for defective pressure switch		
	Check for leaks in the discharge line		
Pump continues to run:	Check for debris in nozzle orifice		
	Discharge hose may be too long		
	Check for clogged strainer/filter		
	Check for restriction in discharge line		
	Check for empty product supply		
	Check for Low Voltage		
Fuse blows:	Check for leaks in the discharge line		
	Check for defective pressure switch		
	System has leaks		
	Air trapped in outlet line or pump head		
	Check for open bypass valve (if equipped)		
	Check for defective or dirty check valve		
Defective pressure switch	Excessive voltage		
	Improper adjustment of pressure switch		
	Damaged or defective wiring harness		
	Defective pressure switch		

Exploded View FSTS-15 (5302838-BLU):





Plumbing Detail





Parts List: FSTS-15 (5302838-BLU):

Ref. #	Part #	Description	Qty
1	TA15Y	15-Gallon Tank (Yellow)	1
2	5058188	Tank Lid w/Lanyard	1
3	5274373	Drain Plug Cap Assembly, 3/4" FGHT	1
4	5116454	3/8" Hose Barb Suction Strainer	1
5	5020251	Hose, 3/8"-1 Brd. x 24"	1
6	5075022	Grommet (5/8" I.D.)	1
7	5051144	Hose Clamp (3/8")	4
8	7V70371	Quick Connect 3/4" Port Fitting x 3/8 HB, 90° Elbow	1
9	5283303	AgSpray Prime 2.2 GPM Pump, 60 PSI	1
10	5117166	#10-24 x 1.25 PH Truss Head Screw	4
11	5281541	Quick Connect Manifold Assembly	1
11.1	5302347	QC Manifold (Main Body)	1
11.1.1	5143421	Quick Connect Manifold - Handle	2
11.1.2	5072514	O-Ring -113	1
11.2	5143430	Flat Washer - Hose Barb Seal	3
11.3	5143431	QC Manifold - 3/8" Hose Straight Barb	2
11.4	5143432	QC Manifold - 1/2" Hose Straight Barb	1
11.5	5143429	Quick Connect Quarter Turn Cap	3
12	5070572-BLK	QR 2-4 GPM Manifold Brace	1
13	5075036	EPDM Push-In Grommet1-3/8" O.D. x 1" I.D.	1
14	5167004	Pressure Gauge, 0-200# (Dry)	1
15	5100961	Formed Bypass Tube	1

Ref. #	Part #	Description	Qty
16	5075018	Grommet	1
17	5020389	Hose, 1/2"-1 Brd. x 43"	1
18	5051114	Hose Clamp (1/2")	2
19	5020524	Hose, 3/8"-1 Brd. x 15 Ft.	1
20	5163100	Low-Flow Spray Wand w/X-26 Tip	1
20.1	5018330	Handgun Tip (X-26)	1
21	5274880	Wand Clips & Screws (Pkg/2)	1
22	5281589-BLU	Frame Weldment	1
23	5034531	5/16-18 x 0.625 Fling Hex Bolt (Locking Patch)	4
24	5117307	3/8-16 x 1.00 Fling Hex Bolt	4
25	5272370-BLK	Tongue Weldment	1
26	5006259	3/8-16 Serrated Fling Hex Nut	4
27	5021102-SVR	4.10/3.50-6 Wheel w/2 1/4" Offset & 5/8" BB	2
27.1	5031175	5/8" Wheel Ball Bearing	2
28	5101065	Hair Pin, #211 x 2.50	2
29	5117323	5/16-18 x 0.75 Fling Hex Bolt	4
30	5038834	Boom Mount L.H.	1
31	5038833	Boom Mount R.H.	1
32	5006307	5/16-18 Serrated Fling Hex Nut	4
33	5277040	Lead Wire Assembly (14 ga, w/Switch), 120"	1
33.1	5157238	15 Amp Regular Blade Fuse	1

Approx. Dimensions



NOTES:

Warranty

LIMITED WARRANTY FOR NEW AG SPRAY EQUIPMENT

WHO MAY USE THIS LIMITED WARRANTY. This limited warranty (the “Limited Warranty”) is provided by Ag Spray Equipment to the original purchaser (“you”) of the Equipment (as defined below) from Ag Spray Equipment or one of Ag Spray Equipment’s authorized dealers. This Limited Warranty does not apply to any subsequent owner or other transferee of the Equipment. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

WHAT THIS LIMITED WARRANTY COVERS AND FOR HOW LONG. Ag Spray Equipment warrants that any new Equipment will be free from defects in material and workmanship for a period of **one (1) year** (homeowner), **90 days** (commercial user), after delivery of the Equipment to you (the “Warranty Period”). The Warranty Period is not extended if Ag Spray Equipment repairs or replaces the Equipment.

WHAT IS NOT COVERED BY THIS LIMITED WARRANTY. This Limited Warranty does not apply to: (1) used Equipment; (2) any Equipment that has been altered, changed, repaired or treated since its delivery to you, other than by Ag Spray Equipment or its authorized dealers; (3) damage or depreciation due to normal wear and tear; (4) defects or damage due to failure to follow Ag Spray Equipment’s operator’s manual, specifications or other written instructions, or improper storage, operation, maintenance, application or installation of parts; (5) defects or damage due to misuse, accident or neglect, “acts of God” or other events beyond Ag Spray Equipment’s reasonable control; (6) accessories, attachments, tools or parts that were not manufactured by Ag Spray Equipment, whether or not sold or operated with the Equipment; or (7) rubber parts, such as tires, hoses and grommets.

HOW TO OBTAIN WARRANTY SERVICE. To obtain warranty service under this Limited Warranty, you must (1) provide written notice to Ag Spray Equipment of the defect during the Warranty Period and within **thirty (30)** days after the defect becomes apparent or the repair becomes necessary, at the following address: Ag Spray Equipment, 1000 Fimco Lane, North Sioux City, SD 57049; and (2) make the Equipment available to Ag Spray Equipment or an authorized dealer within a reasonable period of time. For more information about this Limited Warranty, please call: **800-274-1025** or your local Ag Spray location.

WHAT REMEDIES ARE AVAILABLE UNDER THIS LIMITED WARRANTY. If the conditions set forth above are fulfilled and the Equipment or any part thereof is found to be defective, Ag Spray Equipment shall, at its own cost, and at its option, either repair or replace the defective Equipment or part. Ag Spray Equipment will pay for shipping and handling fees to return the repaired or replacement Equipment or part to you.

LIMITATION OF IMPLIED WARRANTIES AND OTHER REMEDIES. THE REMEDIES DESCRIBED ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES, AND AG SPRAY EQUIPMENT’S SOLE LIABILITY, FOR ANY BREACH OF THIS LIMITED WARRANTY. TO THE EXTENT APPLICABLE, ANY IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE WARRANTY PERIOD, AND THE REMEDIES AVAILABLE FOR BREACH THEREOF SHALL BE LIMITED TO THE REMEDIES AVAILABLE UNDER THIS EXPRESS LIMITED WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN NO EVENT SHALL AG SPRAY EQUIPMENT’S LIABILITY UNDER THIS LIMITED WARRANTY EXCEED THE ACTUAL AMOUNT PAID BY YOU FOR THE DEFECTIVE EQUIPMENT, NOR SHALL AG SPRAY EQUIPMENT BE LIABLE, UNDER ANY CIRCUMSTANCES, FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR PUNITIVE DAMAGES OR LOSSES, WHETHER DIRECT OR INDIRECT. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.