
Replacement Parts

The following drawings show the pumps and their replacement parts. Only genuine replacement parts should be used. Failure to follow this warning can result in damage to property, serious injury or death. If the pump malfunctions or is defective, it should be sent back to Hypro for service.



Mechanical Seal Kit #3430-0604 Includes Items 6 & 7 Bearing Kit #3430-0671 Includes Items 14, 15, 16, 17 **NOTE**: When ordering parts, give QUANTITY, PART NUMBER, DESCRIPTION, and COMPLETE MODEL NUMBER. Reference number are used ONLY to identify part in the drawing and are NOT to be used as order numbers.

Ref. No.	Qty. Req'd.	Part No.	Description	Ref. No.	Qty. Reg'd.	Part No.	Description
1	4	2406-0039	Drain Plug	10	1	1720-0209	O-Ring
2	1	0150-9308C	Pump Casting	11	1	2300-0040	Plug
3	1	2253-0010	Impeller Nut	12	8	2210-0131	Cap Screw
4	1	0400-9308S	Impeller	13	2	22771	Screw
5	1	1610-0058	Key	14	1	2270-0093	Slinger
6	1	3430-0604	Mechanical Seal	15	1	1820-0040	Retaining Ring
7	1	1721-0208	O-Ring	16	2	2005-0006	Bearing
8	1	0755-9300C	Seal Plate	17	2	1810-0001	Retaining Ring
9	1	0757-9300C	Pedestal	18	1	0500-9208	Shaft