## FITTING INSTALLATION GUIDE FOR CONE BOTTOM TANKS

Norwesco cone bottom tanks come standard with a bulkhead fitting installed or the tank may be ordered without a fitting. For instances when you would like to install a smaller or larger bulkhead fitting, would like to install a bolted fitting or would like to install additional fittings, please refer to this guide.

The maximum fitting sizes shown for cone bottom tanks are based on installing the fitting in the standard flat area in the bottom cone of the tank. All cone bottom stands will accommodate maximum fitting sizes. Please contact a Norwesco distributor or Norwesco Customer Service if you would like to install a fitting in any other location.

Gallon		Maximum Bulkhead	Maximum Bolted
Capacity	Slope	Fitting Size	Fitting Size
125	15°	2"	2"
160	45°	2"	2"
175	30°	2"	2"
300	45°	3"	3"
300	30°	3"	3"
310	30°	2"	2"
500	45°	3"	3"
500	30°	3"	3"
550	20°	3"	3"
750	20°	3"	3"
1000	45°	3"	3"
1020	15°	3"	3"
1050	20°	3"	3"
1320	15°	3"	3"
1500	45°	3"	3"
1600	30°	3"	3"
1720	15°	3"	3"
2500	30°	3"	3″
2500	15°	3"	3"
3000	30°	3"	3"
3000	15°	3"	3"
4950	15°	3"	3"
5500	30°	4"	4"
6000	10°	4"	4"
6000	15°	4"	4"
7500	30°	4"	4"
10000	15°	4"	4"
10000	30°	4"	4"