

## FITTING INSTALLATION GUIDE FOR DRAINABLE LEG TANKS

Norwesco drainable leg tanks come standard without a fitting installed. When installing a bulkhead or bolted fitting, please refer to this guide.

The maximum fitting sizes shown for drainable leg tanks are based on installing the fitting in the bottom drainage location. Please contact a Norwesco distributor or Norwesco Customer Service if you would like to install a fitting in any other location.

Gallon Capacity	Maximum Bulkhead Fitting Size	Maximum Bolted Fitting Size
710	3"	3"
1010	3"	3"
1310	3"	3"
1315	3"	3"
1610	4"	4"
2010	4"	4"
2610	4"	4"
3210	4"	4"

Revised 5/6/14